

FEB-24ED TECHNICAL DOCUMENTATION



01-12-08 version 1.0



1- WARNINGS AND PRECAUTIONS1	0
2 - FEATURES	2 5
3.1.1 General description	5
3.1.2 Hydraulic Circuit	4
3.1.2 PCB (Photograph)	9
3.1.3 Gas Circuit	14
3.1.4 Air circuit	18
3.2 - External auto test functions	19
3.3- On board auto test functions and boiler configuration set up	26
3.4 -Trouble shooting + lock out codes	32
3.5- Trouble shooting Flow charts	36
3.6- Assembly and disassembly hydraulic unit	44
3.7- Functional flow charts	47
3.8- PCB Schematic drawing	53



1.- Warnings and precautions

In order for the boiler to function correctly, it is vitally important for the appliance to

be correctly adjusted on installation in accordance with gas installation regulations.

Boiler installation must comply with the conditions described by in the user and installation manual provided with the appliance



Important: Please read the user and installation manual for this boiler carefully.

PLEASE NOTE THAT THE FAULT CODES AND SOFTWARE DIFFER FROM THE FEB24E FAULT CODES. ALWAYS USE THIS MANUAL FOR FAULT FINDING AND TROUBLE SHOOTING ON THE FEB24ED



2.- Features

The boiler FEB-24ED is a wall hung, room sealed, fan assisted,

microprocessor controlled fully modulating gas combination boiler for providing both central heating and domestic hot water.

The boiler has a continuous electronic modulation field. The 24kW boiler has an

output power of between 7.6 kW and 23.7 kW (6,536 and 20,382 Kcal/h).

FEB-24ED



- 1. Central heating thermistor
- 2. Air pressure switch
- 3. Fan
- 4. High limit stat
- 5. Copper heat exchanger
- 6. Expansion vessel
- 7. Combustion chamber
- 8. Ionisation electrode
- 9. Ignition electrodes
- 10. Circulation Pump with Automatic Air Vent
- 11. Modulating gas valve
- 12 Hydraulic assembly
- 13. DHW thermistor
- 14. Safety valve
- 15. Pressure gauge
- 16. Pcb acess panel
- 17. Control panel
- 18. Time clock



Features

Technical data:

Models			FEB-24ED
Category			II2H3P
Туре			C12, C32, C42, C52, C82, B22
Central heating performances	Maximum	kW	23,7
	output	kcal/h	20.382
	Minimum	kW	7,6
	output	kcal/h	6.536
Domestic hot water performances	Maximum	kW	23,7
	output.	kcal/h	20.382
	Minimum	kW	7,6
	output	kcal/h	6.536
Domestic hot water flow 25°C increase (I/r	min)		13,6
Domestic hot water flow rate (I/min)			10 (34°C increase)
Minimum flow rate for activating D.H.W. (I	/min)		2
Operating pressure (bar)	Maximun	Central heating	3
	Maximun	D.H.W.	10
	Minimum D.H.W	activation	0,3
Expansion vessel capacity (L)	-		7
Temperature selection range (°C)	Central heating	Floor Heating	40-60
	circuit	Radiators	60-85
	D.H.W.circuit	·	35-60
Gas inlet pressure (mbar)	Natural G20		20
	Propane G31		37
Gas consumption (Hi)	Natural G20 (m ³ /h)		2,78
	Propane G31 (kg	2,1	
Electrical suplly (V/Hz)	-		220-230V~50Hz
Max power consumption (W)			120
Dimensions (mm)	Height		680
	Width		390
	Depth		250
Connections / Interior Ø in (mm)	Gas Inlet		3⁄4"/Ø18
	Domestic cold wat	er Inlet	½"/Ø15
	Domestic hot wate	r Outlet	½"/Ø15
	Central heating Flo	W	³¼"/Ø22
Central heating return			3⁄4"/Ø22
Flue gas exit temperature (°C)			140
Net weight (kg)			29
Gas type	Natuaral G20	Х	
Propane G31		Х	
CE type examination certificate			99BN794
NOx (according to prNE483)			3
Degree protection			IP-44
Directive 92/42/CEE			* *

Description of functioning



3.- Description of functioning

3.1.- General description

3.1.1.- Hydraulic Circuit

Hydraulic Circuit

FEB-24ED



- 1. Expansion vessel
- 2. Pump
- 3. Low pressure switch
- 4. Central heating thermistor
- 5. Three way valve
- 6. High limit stat
- 7. Air pressure switch
- 8. Venturi
- 9. Fan
- 10. Sealed air box
- 11. Copper heat exchanger
- 12. Combustion chamber
- 13. Ignition electrodes
- 14. Main burner
- 15. Ionisation electrode
- 16. Modulating gas valve
- 17. Gas inlet
- 18. D.H.W Thermistor
- 19. Hot water outlet
- 20. Plate heat exchanger
- 21. C.H. Flow
- 22. Cold water inlet
- 23. C.H. Return
- 24. Safety valve
- 25. By-pass
- 26. C.H.Drain valve



Filling the heating circuit:

In order for the boiler to function correctly, the heating circuit pressure must be at around 1.6 b when it is cold.

Both the boiler and the heating installation must be correctly purged, as air in the

water pipes can cause excessive noise and malfunctioning.

The boiler has an automatic drain valve incorporated to the pump body.

The radiators and upper areas of the heating circuit should be provided with an automatic drain valve.

The procedure for correct filling of the installation is as follows:

- Fill the heating circuit by slowly opening the filling valve .

- Close the filling valve when the water pressure gauge shows that a pressure of 1.6 bars has been reached.

- Ensure there is no water leakage from the installation or boiler. Check all the connections thoroughly.

Domestic Hot Water Functioning (DHW):

Water begins to circulate through the domestic circuit of the boiler. The cold water

flows through the 3-way valve, this action ports the 3 way valve and micro switch into DHW mode.

Water heated in the primary circuit flows through the plate heat exchanger to heat up the water coming from cold mains water supply. As the cold water circulates, it is heated up in the plate heat exchanger.

The temperature of the DHW is controled by the DHW thermistor, and limited for safety

Heating Functioning:

The pump starts up and water begins to circulate through the radiator circuit. The fan and the burner then start up. The heating output temperature is controlled at all times by the heating thermistor.

Draining the heating circuit:

The boiler has a drain valve incorporated for draining the heating circuit when necessary The safety valve mustn't be used for this purpose.





Description and function of the hydraulic components:

Compact hydraulic unit: (Part number MCB2190)

This unit consists of various hydraulic components: circulating pump, safety valve, drain valve, plate heat exchanger, 3-way valve, flow restrictor, automatic drain valve and automatic bypass. All these together form a compact unit.



- 3. Draining valve 6.Auto
- 5.Three way valve 6.Automatic air vent

Circulating pump head:(Part number MCB3050)

Operates in both CH and DHW mode. Circulation of the primary circuit either to the radiators or to the plate heat exchanger when operating in DHW mode. Pump combines a manual and automatic anti-blocking system The capacity of this pump has a mamometric head of 5 metres for the 24kW boiler.

Safety valve:

Also called an overpressure valve, Its function is to prevent the heating circuit exceed ing 3.0b pressure DO NOT USE FOR DRAINING BOILER



Drain valve:

This component allows the heating circuit to be drained. Finger operated located to the right hand side of the safety valve. (Part number MCB2180)

3 Way valve:

Integrated within hydraulic unit, operates whenever a hot tap is opened.

This action activates the micro switch and ports the primary circuit away from the radiators to the plate heat exchanger In order to produce hot water at the taps.

(Part number MCB2190 Complete unit)

Micro switch

Located on the 3 way valve brass diaphragm housing. Activation ocours when the white switch tip which sits on the diaphragm push rod in CH mode is released as the diaphragm push rod ports the 3 way valve to DHW.

This action places the PCB into DHW mode allowing the boiler to commence the ignition sequence.(Part number MCB2320)

Flow restrictor

Located within the hydraulic unit between the brass inlet union and the cold inlet port on the hydraulic unit. This component restricts the flow of water into the boiler to 10 litres per min.(Part number MCB2240)

NOTE

THIS RESTRICTOR IS NOT SUPPLIED WITH NEW HYDRAULIC UNITS. ALWAYS ENSURE THAT THIS ITEM IS REPLACED INTO THE HYDRAULIC UNIT IF ANY WORK IS CARRIED OUT ON THE HYDRAULIC UNIT













Expansion vessel: (Part number MCB2005)

The expansion vessel is a hermetically closed receptacle with two chambers separated by an SBR membrane. One chamber contains nitrogen (air) and the other is filled with the water from the heating circuit. It has a capacity of 7 litres.

The function of the expansion vessel is to absorb the increase in volume of the heating circuit water when it is heated up.

The amount of expansion by the expansion vessel depends on the temperature selected by the user for the heating circuit, and on the total volume of the heating circuit.

Automatic bypass:

The bypass is located inside the hydraulic unit. It joins the heating outlet and return.

It is preset, only opening when the pressure between the bypass inlet and outlet exceed 0.3 b

Its purpose is to assist when there is a large loss of load in the circuit and the pump

consequently has difficulty in moving the water. When the bypass opens, an amount

of water which was flowing towards the radiators is made to circulate directly to the

return pipe, thus making the work of the pump easier.

Central heating low pressure switch: (Part number FCB1480)

This indicates the pressure inside the heating circuit is correct. If the pressure is under 0,5 bar the switch opens and the boiler locks out (F3)





The expansion vessel pressure is 1 bar, with zero pressure in the heating circuit



3.1.2.- Main P.C.B (Part number MCB3000)



Description of functioning



Anti Freeze Safety:

When the temperature (read by heating thermistor) falls to 6°C the pump will run until the temperature reaches to 9°C. If the temperature continues to fall and the heating thermistor reads less than 3 °C the boiler will light up at minimum power until the heating circuit temperature reaches 20° C after that the pump



runs for a further 30 minutes. After the pump has run for 1 hour the PCB

reads the temperature if it is between 3° and 6° C the pump will stop running

If the burner is burning for over 3 hours, the control circuit stops the burner, reads the temperature and if the temperature is lower than 3 degrees the burner will relight.

Pump Antiblock safety: (Keep fit)

If during during the last 23 hours the pump has not run the PCB will run the pump for 30 seconds

Overheating:

If the heating thermistor detects a lower temperature than 50°C and there is a higher output than 95% after 5 minutes the boiler will shut down then relight

Fuzzy logic

This program operates only in central heating mode the principal purpose is to detect the size of the heating load connected to the boiler and to reduce unnecessary gas use.

In heating demand the boiler will only operate at minimum burner pressure for (4.0mb propane) for the 1st 30 seconds after the flame is established.

After this period of minimum burn the boiler will then modulate to increase the power to the heating system if required.









If the heating selected temperature is achieved in less than 5 minutes. The next heating cycle will result in the minimum burn period to be extended to 5 mins.

If the burner continues to burn at minimum power for 5 minutes without restarting the Modulation process can then start to increase the burner power if required.

If during the 5 minutes at minimum power the boiler shuts down, the above sequence is repeated.

Set point Security

When the boiler is working in D.H.W., with the burner lit with at least the minimum power, and the DHW energy requirment is lower than the minimum power.

The above situation will result in the following if DHW temperature is greater than DHW selected temp (+ 8° C) or+ 4° C for more than 15 seconds then the boiler starts to work in ON-OFF cycling mode.

While the boiler is in ON-OFF mode, the boiler starts at least 8 seconds and stops working for; at least, 4 seconds, and always working at the minimum power. The boiler comes out of this ON-OFF mode when DHW temperature is lower than DHW set point - 4° C or when DHW temperature is lower than DHW set point during more than 45 seconds and the boiler begins to regulate again

85° C Security

While DHW is working, if the temperature of the primary circuit reaches 85° C, the boiler will limit (by modulation) not to go over 85° C. This security works while DHW temprature is lower than DHW selected temprature.

88º C Security

While DHW is working, if the temperature of the primary circuit arrives up to 88° C the gas valve closes and the burner will shut down, the pump continues to run in order to reduce the temperature of the primary circuit. When the temperature of the primary circuit reaches at DHW selected temperature + 20° C the boiler will relight and modulate.



92º C Security (without DHW demand)

If heating thermistor value arrives to 92° C, the pump will run making cycles of 10 second starting and stopping. If the temperature remains high the pump will continue cycling until a lower temperature is detected.

180 minutes security:

When the burner is working continuously for 180 minutes, the burner will shut down for a period and if it is necessary, the burner will relight.

Control and safety components:

Main PCB:

This circuit governs the correct functioning of all the boiler functions.

High limit thermostat: (Part number MCB2250)

This is in direct contact with the the main heat exchanger (dry pocket) It controls the temperature of the outlet circuit, protecting the boiler against overheating. It cuts out at 102° C.

The contacts of this thermostat are normally closed. When the thermostat is activated, the boiler will lock out (F4 block). The thermostat resets automatically,





Thermistors:

There are two thermistors incorporated to the boiler. The DHW thermistor is screwed into the 3 way valve at the hot water outlet, and is in direct contact with the hot water

exiting the boiler. (Part number FCB1080) faulty or out of range thermistors will cause the boiler to lock out with F11.(*N.B. the boiler will only read the values of this thermistor when working in hot* water mode)

The central heating thermistor is located on the left hand side of the primary heat exchanger. This thermistor controls the temperature of the primary circuit within the boiler.

The thermistor is also responsible for first stage over heat protection any overheating within the boiler is detected and controlled by the pump cycling in 10 second intervals until a lower value is reached.

The thermistor also reads the temperature for the built in frost protection. Faulty or out of range thermistors will cause the boiler to lock out (F13) (Part number MCB2245)







Note: When the heating is working and within the range shown in the table below If the thermistor is out of range the boiler will lock out, automatically "resetting" again when the working range is entered. In case DHW is working the boiler continues work even if the led displays fault. The boiler uses the heating thermistor to regulate DHW temperature.

Relation between Temperature-Voltage and			
Thermis	stor nominal Resis	stance	
Temperature	Voltage	Resistance	
(0 °)	(Volts)	(k)	
85	0.92	1.44	
80	1.01	1.65	
75	1.15	1.91	
70	1.28	2.21	
65	1.41	2.57	
60	1.54	2.99	
55	1.71	3.51	
50	1.93	4.13	
45	2.13	4.87	
40	2.34	5.78	
35	2.55	6.89	



3.1.3.- Gas Circuit

Characteristics of the gas components:

Gas valve: (Part number FCB1130)

This is one of the most important components of the boiler. It regulates output power, gas consumption, combustion, modulation.

The SIT-845 SIGMA valve is equipped with two on/off safety valves powered by the PCB at 230V AC, plus a modulating valve also powered by the PCB in DC ensuring continuous modulation.



FCB1130

The valve has two test nipples (A) is the inlet supply pressure (B) Is the outlet pressure from the modulating section of the valve (Burner pressure can also be tested at the inlet pipe to the burner)

Spark generator



This component has 2 functions the 1st is to create a high tension voltage at the spark electrodes. The unit also provides a connection for the 230v ac from the PCB to the twin gas valve solenoids (EV1 +EV2)

(Part number MCB3055)

Gas pressure modulation:

This is a progressive modulation type boiler, i.e. it automatically adjusts its gas consumption to the USER's needs at all times.

When the boiler needs to heat water at maximum power, there is maximum gas pressure to the burner and, inversely, when modulation is at a minimum it uses minimum power and the pressure to the burner is also minimum.

The gas pressure to the burner varies according to the gas type (propane/ natural)

Description of functioning





FEB-24ED:

Installation Menu.

To enter in the Installation menu, with the left knob out of the O position and the right knob must be placed in to the middle, more or less at 75°C, after the boiler must be turned off, turned on, turned off again and finally turned on again, using the left knob, in every movement you cannot stay more than 3 seconds and it'll appear "- -" at the display, and before 5 seconds, the right knob must be moved to the minimum ("summer" position) and them the display shows "P1" and another value alternately.



To move between different steps, the left knob (DHW) is used and to change the selected step's value, the right knob (CH) is used. When the right knob (CH) is in summer position, the display shows the stored value of the selected step. And it is pushed the main board button when a new value wanted to be stored, then the display shows "- -" to indicate that the value has being stored. To leave installation menu it can move the right knob back to the O position.

These are the 7 Installation Menu's Steps:

Step 1. Select gas type. The display shows "P1" and the value selected "6n" or "LP". "6n" is for Natural Gas and "LP" for propane/butane. When the gas type is stored the value of the maximum and minimum power will automatically change. When the right knob (CH) is in summer position, the display shows the stored value of the selected step. And must be pushed the main board button when a new value wanted to be stored, then the display shows "- -" to indicate that the value has being stored.

N.B

Gas change requires that the correct injectors for the gas type are replaced, and the adjustment of the maximum and minimum pressures on the gas valve and the correct electrical values to be set on the PCB.



Gas Type	Maximum Power	Minimum Power
Natural Gas	74%	35%
Propane	92%	46%

Step 2. Maximum Heating Power. The display shows "P2" and the value selected alternatively. When the right knob (CH) is in summer position, the display shows the stored value of the selected step. And must be pushed the main board button when a new value wanted to be stored, then the display shows "- -" to indicate that the value has being stored. The value is limited between 20 and 99.

Step 3. Post-Circulation time of the pump after an ambient thermostat cut-off. Display shows "P3" and the selected time (when right knob is in summer position). Default value is 1 minute and it can be changed with right knob until 85 minutes. To store the selected value use the main board push button.

Step 4. Type of heating circuit (radiators or floor heating). The display will show P4 and it will alternate between this P4 and the selected option, RA (radiator) or SU (floor heating). Using right knob (CH) RA (radiators) or SU (floor heating) can be selected. In case floor heating (SU) is selected, the set point must be stored. Using the right knob (CH) it can be selected the value between 40 and 60 ^aC and using the main board button the value will be stored and the display will show "- -" again to indicate that the value has being stored. When this option (SU) is chosen, the right knob (CH set point) won't be able to select the CH set point in normal operation; it will be always the stored value in the configuration menu.

Step 5. External Probe. Display shows "P5" and "X" the selected curve alternatively. If SE=0 no external probe will be connected. In all the other cases("A", "b", "C" or "d") it will be selected the best option for the external probe. To store the value, use the main board push button.

Step 6. Flue System Cleaner. Display shows "P6" and a hot water tap must be opened to activate this function. It'll turn the boiler on and set the maximum power to clean the flue system.



The table below shows the gas pressure values at the burner for each model of boiler:

OUTPUT (kcal/h)	BURNER PRESSURE IN mb OF WATER GAUGE	
	BOILEF	R 24KW
	Natural	Propane
20382	18.0	35.0
18060	13.3	27.0
16340	16340 11.2 23.	
14620	8.6 19.0	
12900	7.0	14.8
11180	5.3 11.9	
9460	4.0 8.6	
7740	2.3 5.8	
6536	1.3 3.2	
Ignition Pressure	4.0 8.0	
Ø Injectors (mm)	1,14 0,75	



Important: It is very important to know that when you are making the gas regulation you may use the values of this table. The values should be equal or lower never higher. For example if you are making a maximum natural gas regulation the table says 18.0mb so you achieve 18.0 mb or less than 18.0mb

Changing the gas:

This boiler is designed to function using PROPANE GAS or NATURAL GAS GAS.

To change the type of gas used, the only components that need to be changed are the injectors. The injectors corresponding to the gas to be used are fitted as shown in Table 3.

After the injectors have been changed, the gas is to be adjusted depending on the type used, as shown in Table 3.

- Maximum pressure adjustment (@Gas valve)
- Minimum pressure adjustment (@Gas valve
- Ignition pressure adjustment (see step 5 T5 adujusting boiler parameters) using built in auto test feature)



Description of functioning



3.1.4- Air Circuit

Characteristics of the air circuit components:

Fan: (Part number MCB2030)



The function of the fan is to draw in air from the outside and evacuate the burnt gases produced during combustion. The 24kW boiler fan has a power of 35W. Part number MCB2030

Air pressure switch: (Part numberMCB2105)

This component ensures that the fan is running, that there are no obstructions anywhere in the flue or in the flue venturi, also checks that the flue is installed and working correctly 24kW boiler -> 140/89Pa pressure switch

If a pressure switch is calibrated to 140/89 Pa, for example, this means that the pressure switch contacts are activated at a differential pressure of 140Pa (1.4 mb) and deactivated at 89Pa (.89 mb).

To measure the differential pressure, first measure the pressure using the water column in one of the Venturi gauges, and then with the water column in the other. The result will be the sum total of both.

This data is to be taken as an approximate value only, as variations of a few Pascals

occur in the measurements while the fan is running.

Flue Venturi : (Part number MCB2100)

This is fitted to the fan outlet pipe. When the air or flue gases flow through it, a pressure difference is produced which must be great enough to activate the differential air pressure switch.



PLEASE NOTE THAT DURING PERIODS OF SHUT DOWN. THE FLUE VENTURI MAY BECOME BLOCKED WITH INSECTS. IT WILL BE NECESSARY TO REMOVE AND CLEAN THE VENTURI THE VENTURI WILL ONLY FUNCTION CORRECTLY WHEN FITTED WITH THE LONGEST PART FACING UPWARDS(- TO TOP)



3.2- Troubleshooting

A.S.S. Control

It's an appliance connected to BMF net from the main control board of the boiler, it's used by the A.S.S. (After Sales Service) to configure and adjust the boiler parameters.

CONFIGURATION	AUTOTEST
1 General configuration 10 - P4: Electric value for maximum heating 2 - FA: Historical faults 11 - hC: Total time boiler ON (dC, SC) 3 - ICA: Type of boiler 12 - hL: Total time burner ON (dC, SC) 4 CAL: Radiators / Floor heating 5 SE: External sensor 6 H2: Stetric value for maximum DHW 8 P2: Electric value for the minimum 9 P3: Electric value for the starting	P1: Pump / 3 way valve / Filing tap P2: Fan / Spark system P3: Adjustment of maximum power P4: Adjustment of minimum power P5: Adjustment of theiting power P6: DHV modulation to H2*C P7: Adjustment of heating power Modulation with radiators to 85*C Modulation with radiators to 85*C
CONFIGURATION AUTOTEST	AUTOTEST DETAILS
DISPLAY 1 - DHW T User's T + DHW T 2 - Heating user's T + Outlet heating T 3 - DHW T + Gas power % 4 - DHW T + Gullet heating T 5 - DHW flow + Pressure 6 - Outlet heating T + Inlet heating T	ACTIVATE / DEACTIVATE + F01 = Lighting fault F02 = Air fault F03 = Heating pressure F04 = Safety thermostat F05 = Flame detection F04 = Safety thermostat F05 = Flame detection F12 = Inlet heating thermistor F13 = Outlet heating thermistor

To enter in the different menus, the ON/OFF, WINTER and COMFORT push buttons must be used.

- ON/OFF ===> Shows boiler status.
- WINTER ===> Adjust boiler parameters (AUTOTEST)
- Comfort ===> Configure the boiler.

Showing boiler status.

The symbols from the top of the display show the actual state of the different

inputs/outputs and with both 7 segment displays show set points, temperatures,

water flow, pressure and power of the boiler.

The values of visualization are shown in groups of two and using the push buttons to increase/decrease D.H.W. set point all the different groups will be shown





The different groups are the following:

- D.H.W. Set point and temperature (tap symbol).



- Central Heating set point and temperature (radiator symbol).



- D.H.W. Temperature (°C) and gas valve power (%).



- D.H.W. Temperature and Central Heating Temperature (tap and radiator symbol).



- Water flow and pressure (symbols I/min y bar). NOT AVAILABLE ON FEB24ED





- Input and output temperature in the exchanger (No NTC at the output appears "- -")



AUTOTEST. A.S.S. TEST. Parameters adjust.

It has 7 different steps:

- Step 1. Switch ON/OFF the pump and 3-way valve. The display shows P1.



Light button: When pressed, display shows D.H.W. Temperature and C.H. Temperature.

- D.H.W. set point increase button: Pump ON / OFF.
- D.H.W. set point decrease button: Change 3-way valve.
- Step 2. Switch ON/OFF the fan and sparks system. The display shows P2.



- Light button: When pressed, display shows D.H.W. Temperature and C.H. Temperature.

- D.H.W. set point increase button: Fan ON / OFF.
- D.H.W. set point decrease button: Activates Spark System for ten seconds.



- Step 3. Maximum DHW Power Regulation. Display shows P3 and electrical

value. Limited between 56 and 99.



- Light button: When pressed, display shows D.H.W. Temperature and electrical value of this step.

- D.H.W. set point increase/decrease button: To set the electrical value.
- Winter Button (Central Heating): Push to store the selected value

- **Step 4.** Maximum DHW Power Regulation. Display shows P4 and electrical value. To adjust this value use the same instructions that are used in Step 3.Limited between 20 and 55.





To adjust this value use the same instructions that are used in Step 3.Limited between 20 and 60.



- Step 6. Check the boiler operation, sets the DHW temperature to 42°C.

Display shows P6. No action possible in this step. Pushing light button, DHW temperature and hundred percent value of the gas valve are shown.

- Step 7. Regulation of maximum heating Power and regulation at 85°C. Display

shows P7 and electrical value. To adjust this value use the same instructions that are used in Step 3.Limited between 20 and 99 for radiators and between 20 and 70 for floor heating. Pushing UNLOCK button the fault memory will be cleared.





First 2 digits indicate the boiler type depending on type of water pressure detector, if

the boiler uses water pressure switch, the boiler will be 00 and if the boiler uses water pressure sensor (digital pressure gauge) the boiler will be 04.

Second 2 digits are explained in following tables:

First Number from	Heating Circuit Type (CA)		Heating Plumb Delay (Tpb)		Plumb Cy	cling (PC)
"YY"	rA	SU	1min.	2-99min.	OFF	ON
0	Х		Х		Х	
1		Х	Х		Х	
2	Х			Х	Х	
3		Х		Х	Х	
4	Х		Х			Х
5		Х	Х			Х
6	Х			Х		Х
7		Х		Х		X



Second digit from "YY"	External probe (SE)
0	Without probe
А	Curve A
b	Curve B
С	Curve C
d	Curve D

- Step 2. Latest Faults. Shows an historical with fifty last faults of the boiler. At first its shown "FAI" (historical fault) and the number of faults occurred since last time fault clean. Later using increase/decrease CH set point buttons is selected different faults. It shows from "F1" to "F50" and the number of occurred fault ("XX"). If it shows "--"means that somebody has entered in the fault menu from ASS Control.



- Step 3. Type of boiler. Using increase/decrease CH set point buttons is selected different type of boiler. From 00 to 03 means that the boiler has water pressure switch and if its from 04 to 13 the boiler has water pressure sensor. To store the selected value use the comfort button.



- Step 4. Type of heating circuit (radiators or floor heating). The display will show CA as it's shown in the picture and the selected option, RA (radiator) or SU (floor heating). Using increase/decrease CH set point buttons is selected and pressing comfort the value is stored. In case floor heating (SU) is selected, the set point must be also stored. Select the floor heating set point value using increase/decrease CH set point buttons (between 40 and 60) and pressing comfort the value is stored. When this option (SU) is chosen, CH set point won't be able to select the CH set point in normal operation; it will be always the stored value in the configuration menu.





- Step 5. External Probe. Display shows "SE" and "X" the selected curve. If SE=0 no external probe will be connected. In all the other cases it will be selected the best option for the external probe. To store value, use the comfort button to store the selected value.



- Step 6. Post-Circulation time of the pump after the room thermostat cuts-off. Display shows "tPb" and the selected time. Default value is 1 minute and it can be changed with increase/decrease CH set point until 99 minutes. To store the selected value use the comfort push button.



- Step 7. Pumb Cycling. Display shows "PC" and "On" or "OF" depending on the state of the pump cycling function. Select the desired value using increase/decrease CH se point buttons and store it with the comfort push button.

When the boiler is working in central heating function at a high temperature if a tap is opened, very hot water is produced at the initial flow to tap. To avoid this possibility pump cycling function can be used. In that case, if the DHW is too high (DHW set point + 20° C), the pump will make ON-OFF to try to regulate the water temperature. When the temperature goes in normal values the pump will work normally.





- **Step 8**. Maximum DHW Power Regulation. Only displays the selected value in AUTOTEST (P1 XX).

- **Step 9.** Minimum DHW Power Regulation. Only displays the selected value in AUTOTEST (P2 XX).

- Step 10. Start-up Pressure Regulation. Only displays the selected value in AUTOTEST (P3 XX).

- **Step 11.** Maximum heating Power. Only displays the selected value in AUTOTEST (P4 XX).

- Step 12. Boiler Working Time. Only shows how long has being the boiler working in hours (h), days (d) or weeks (w).

- Step 13. Burner Working Time. Only shows how long has being the burner working in hours (h), days (d) or weeks (w).

- Step 14. State of manufacture. (EF XX).
- Step 15. Main board software version. i.e. "CC 1.1".
- Step 16. Front panel control software version. i.e. "CP 2.3".

EATING SELECTION WITHOUT EXTERNAL AUTO TEST

Selection of heating mode (radiators/ under floor heating) The boiler can be configured for either heating radiators (rA) or under floor heating(SU)

2 configuration methods are available via the digital control knobs

a- Using the configuration menu page 29

- b- Doing the following
- 1- Set the Left Regulating Knob (DHW) to the right (maximum) and the right knob (CH) to summer position now push the main PCB push button.
- 2- The display will show CA as shown in the photo and will alternate between rA and CA if the mainboard button is pressed before 10

MAIN PCB PUSH BUTT<mark>O</mark>N





seconds time, the opposite option will be chosen and the display will show "- -" to indicate that a different option has being stored and after it will show the stored option. In case floor heating (SU) is selected, the set point must be stored. Using the right knob (CH) it can be selected the value between 40 and 60 °C and using the main board button the value will be stored and the display will show "- -"again to indicate that



4. If nothing is touched in 10 seconds the selected value will be stored. If the Left Regulating Knob is set to O position it'll also be stored the selected value.

5. Every time the boiler is switched on, it shows the selected value in the display for a few seconds, if the heating circuit is radiator it will show rA and if the heatingcircuit is floor heating it will show SU.

Adjusting boiler's parameters. AUTOTEST

To enter in the AUTOTEST function menu, both knobs must be place to minimum (to the left), DHW knob in O position and CH knob in summer position and then push the main board button once, the boiler is in the AUTOTEST menu.

To move between different steps, the left knob (DHW) is used and to change the selected step's value, the right knob (CH) is used. When the right knob (CH) is in summer position, the display shows the stored value of the selected step. The main board button must be pressed to store the new selected value. The display will then shows "- -"to indicate that the value has being stored. To leave AUTOTEST menu it can move the right knob out of O position and taking it back to the O position.

- Step 1. Pump in operation. Display shows t1.3.1.-General description











- Step 3. Maximum DHW Power Regulation. Display shows t3 and the electrical value alternately. When the right knob (CH) is in summer position, the display shows the stored value and turning clockwise the right knob the selected value can be changed. Once it's selected the desired value, it can be stored pushing the main board button, then the display shows "- -" to indicate that the value has being stored. The electrical value is limited from 56 to 99. (LPG VALUE 93)

- Step 4. Minimum Boiler Power Regulation. Display shows t4 and the electrical value alternately. When the right knob (CH) is in summer position, the display shows the stored value and turning clockwise the right knob the selected value can be changed. Once it's selected the desired value, it can be stored pushing the main board button, then the display shows "- -"to indicate that the value has being stored. The electrical value is limited from 20 to 55. (LPG VALUE 46)

- Step 5. Start-up Pressure Regulation. Display shows t5 and the electrical value alternately. When the right knob (CH) is in summer position, the display shows the stored value and turning clockwise the right knob the selected value can be changed. Once it's selected the desired value, it can be stored pushing the main board button, then the display shows "- -"to indicate that

the value has being stored. The electrical value is limited from 20 to 60 (LPG VALUE 20)

- Step 6. Check the boiler operation, sets the DHW temperature to 42°C. Display shows t6. No action possible in this step.

- Step 7. Regulation of maximum heating Power and regulation at 85°C.

Display Shows t7 and the electrical value alternately. When the right knob (CH) is in summer position, the display shows the stored value and turning clockwise the right knob the selected value can be changed. Once it's selected the desi







5







Description of functioning

red value, it can be stored pushing the main board button, then the display shows "- -"to indicate that the value has being stored. The electrical value is limited from 20 to 99 when heating circuit is radiators (RA) and from 20 to 70 when heating circuit is floor heating (SU). (LPG VALUE rA 70)

Boiler Configuration Menu.

To enter in the Configuration menu, both knobs must be place to minimum (to the left), DHW knob in O position and CH knob in summer position and then push the main board button twice, then the boiler is in the Configuration menu. To move between different steps, the left knob (DHW) is used and to change the selected step's value, the right knob (CH) is used. When the right knob (CH) is in summer position, the display shows the stored value

of the selected step. And must be pushed the main board button when a new value wanted to be stored, then the display shows "- -"to indicate that the value has being stored. To leave Configuration menu it can move the right knob out of O position and taking it back to the O position.

These are the different Configuration Steps:

- Step 1. Main Configuration Viewer. It can not be modified. Alternately shows in the display "Cn" "XX" "YY", where "XX" is the boiler class (class 00) and "YY" refers to the boiler configuration, as the following boards.

First 2 digits indicate the boiler type depending on type of water pressure detector, ifthe boiler uses water pressure switch, the boiler will be 00 and if the boiler uses water pressure sensor, the boiler will be 04.

First Number from	Heating Circuit Type (CA)		e Heating Pump Delay (Tpb)		Pump Cyc	cling (PC)
"YY"	rA	SU	1min.	2-99min.	OFF	ON
0	х		Х		Х	
1		Х	Х		Х	
2	Х			Х	Х	
3		Х		Х	Х	
4	Х		Х			Х
5		Х	Х			Х
6	Х			Х		Х
7		Х		Х		Х

Second 2 digits are explained in following tables:



En

MAIN BOARD PUSH BUTTON





Second digit from "YY"	External probe (SE)
0	Without probe
А	Curve A
b	Curve B
С	Curve C
d	Curve D

I.E. A boiler that shows "Cn" "00" "3B" in this step means that is a boiler type 00 (with pressure switch) and it is configured with 3 what means that the heating circuit is floor heating (SU), its time to stop the pump after heating switch off is greater than 1 minute and the pump cycling option is activated. Looking "b" it can be known that must be connected a probe with curve type B.

- Step 2. Latest Faults. Shows an historical with ten last faults of the boiler. At first its shown "hF" (historical fault) and the number of faults occurred since last time fault clean alternately. Later using right knob is selected different faults. It shows from "F0" to "F9" and the number of occurred fault ("XX") also alternately. If it shows "- -" means that somebody has entered in the fault menu from TAS Control.



- Step 3. Type of boiler. It shows alternately "ti" and the number of the type of boiler selected. If the value stored is 00 to 03 means that the boiler has presotat and if the value is 04 to 08 means that it has pressure sensor. With the right knob at the summer position, the value stored is shown and using this knob we can select the desired value, to store it just push the main board button and



"--" will be displayed meaning that the value is stored

- Step 4. Type of heating circuit (radiators or floor heating). The display will show CA as it's shown in the picture and it will alternate between this CA and the selected option, RA (radiator) or SU (floor heating). Using right knob (CH) RA (radiators) or SU (floor heating) can be selected. In case floor heating (SU) is selected, the set point must be stored. Using the right knob (CH) it can be selected the value between 40 and 60 ^aC and



using the main board button the value will be stored and the display will show "--"again to indicate that the value has being stored. When this option (SU) is chosen, the right knob (CH set point) won't be able to select the CH set point in normal operation; it will be always the stored value in the configuration menu.



- Step 6. Post-Circulation time of the pump after room thermostat cut-off

Display shows "tP" and the selected time (when right knob is in summer position). Default value is 1 minute and it can be changed with right knob until 85 minutes. To store the selected value use the main board push button.

- Step 7. Pump Cycling. Display shows alternatively "PC" and "On" or "OF" (when right knob is in summer position) depending on the state of the pump cycling function. Select the desired value using right knob (CH) and store it with the main board push button. When the boiler is working in central heating mode at high temperature if a hot tap is opened, the initial flow at the tap will

very hot To reduce the initial temperature at the tap the pump will cycle to decrease the heat transfer to the DHW. In the case, if the DHW temp is too high (DHW set point + 20° C), the pump will make ON-OFF to try to regulate the water temperature.When the temperature goes in normal values the pump will work normally.









5 E









Failures and Fault Finding:

The different type of failures the boiler will show with a lockout light:

F01

The boiler trys 3 times to establish the flame: each sequence lasts 6 seconds between each sequence the stop time is 5 seconds If the ionisation electrode fails to detect a flame the boiler will lock out (F1)



SPARK GAS VALI/E	
FLAME	
BLOCK	
	►

When the boiler is working and the flame fails due to a malfunction of the gas valve or ionisation electrode after 1 second without flame detection the boiler will shut down (gas valves) The boiler will then attempt to relight if no flame is detected the boiler will lock out (F1)



POSSIBLE CAUSES

-NO GAS

-NO SPARK

- FAULTY GAS VALVE
- FAULTY IONISATION ELECTRODE
- FAULTY PCB



F02

In the lighting up process the PCB checks if the air pressure switch contacts are open prior to the fan starting, if after 3 minutes if the air pressure switch contacts remain closed then the boiler will lockout F2 (F21 IN HISTORICAL FAULTS)

In the lighting up process the PCB checks if the air pressure switch contacts are closed. If after 6 minutes the air pressure switch contacts remain open the boiler locks out

If the air pressure switch contacts open whilst the boiler is running another lighting up process will take place after 2 seconds. If the air pressure switch doesn't close after 6 minutes the boiler gets locks out F2 (F22 F23 HISTORICAL FAULTS)

Possible causes:

- Fan failure
- Air pressure switch failure
- Obstruction in the flue or in flue venturi.
- Faulty PCB

F03

If the heating circuit's pressure falls below 0.5 b, or the central heating low pressure switch fails (contacts open) the boiler locks out. (F31 OR 32 HISTORICAL FAULTS)

F04

If the high limit thermostat activates at 102°C) or fails (contacts open) the boiler locks out.

F05

If there is any failure in the software protections of the boiler control program the boiler gets locked. The user can not reset this fault, the circuit remains blocked. (F 51 TO 58 HISTORICAL FAULTS)

F06

The boiler locks out if a flame is detected flame in the following cases:

If the burner lights, before the gas valve is opened and flame is detected for 6 seconds

If the burner shuts down once the gas valve is closed, but flame continues for 6 seconds

When the boiler locks out with the above fault, the pump and the fan run or remain working. This fault can be reset by the user.

F8

If there is any failure in the control panel PCB F8 will be displayed the control PCB will need replacing. Part number (MCB3005)



F10

This fault that occurs when there is a problem with the gas valve or PCB. As the burner shuts down the solenoids on the gas valve. These close one at a time until the flame extinguishes. If the flame remains on for 5 seconds the PCB will repeat the shut down by turning off the solenoid that failed the 1st time. If a flame continues to be detected after the 2nd shut down sequence the boiler will lock out.

Possible causes:

- PCB failure (one of the electrovalve relay is broken)
- Gas valve failure

F11

Occurs when the DHW thermistor is out of range, open or short-circuited

If this fault ocours the heating mode will work normally and the DHW mode will

also work but using the heating thermistor as reference to heat the DHW.

This fault will auto-reset when the thermistor is in range.

F13

It's a failure of the heating thermistor, that it is out of range, open or short-circuited. If this fault occurs, the boiler blocks. This fault auto-reset, when the thermistor returns within normal operating range.

Possible causes:

- Heating thermistor failure
- Faulty PCB
- Minimum very high

NC

No Comunication. It's a comunication error between main control circuit and front panel circuit.

NOTE: Apart from the failure codes, the word "Err" may appear on the control panel.

Meaning: If it appears on the 4 digit display, it means that there is no communication

between the control card and the control panel card.



This may be caused by a poor connection of the 5-way cable joining the two PCB's; "Err" may also appear very briefly on the display when the boiler is plugged into the mains or when entering auto-test mode; in this case it does not necessarily indicate a failure.

In the A.S.S. (Auto test unit) the fault codes are stored in this way: F18 Ignition failure (F1)

F 21, F22

Fault on pressure switch system. During the start before up and before the fan runs the APS contacts must be open lock out ocours after 3mins if the contacts remain closed (F21)

If the contacts are open prior to the start up and fail to close afer 6 minutes then lock out will ocour after a maximun time of 6 minutes if the contacts remain open. (F22)

F 31

Fault on water circuit of the boiler. The heating circuit is empty or the pressure detected is lower than 0.5 bar

F 32

Fault on water circuit of the boiler. The central low heating pressure switch is faulty or disconnected

F 51, F 52, F 53, F 54, F 55, F56, F 57, F 58

These faults are internal electronic faults of the main control circuit.

F 61

Fault in flame detection. Detects flame in burner after closing gas valve.

F 62

Fault in flame detection. Detects flame for 10 seconds when the boiler is not demanding the burner to burn.

F 63

Fault in flame detection. Detects flame in burner start before opening gas valve.



Fault Finding: Boiler FEB-24ED











HEATING & HOT WATER











6. SPARK WORKS BUT NO FLAME/FLAME FAILS AFTER IGNITION.















3.3- Assembly and disassembly instructions

PLEASE NOTE THAT THE HYDRAULIC UNIT CONTAINS A FLOW RESTRICTOR. THIS IS LOCATED IN THE COLD WATER INLET PORT WITHIN THE UNIT. FAILURE TO REFIT THIS PART WILL ALLOW AN EXCESSIVE FLOW FROM BOILER. THIS WILL RESULT IN TEPID OR LUKE W

FLOW IS RESTRICTED

Changing the entire hydraulic unit:

- Drain the heating circuit and the DHW circuit.

- Unplug the boiler from the mains.

- Disconnect the electrical connections, i.e. the 3-way valve micro switch and thermistor connections.

- Remove the heating return pipe (1) and the heating outlet pipe (2) from the hydraulic unit.

- Remove the pressure sensor from the heating return pipe for ease of handling.

- Remove the heating outlet pipe (3) from the main heat exchanger, for ease of handling.

- Remove the screws holding the hydraulic unit to the boiler base (they are on the underside).

- Release the hydraulic unit from the lower connectors (DHW inlet and outlet and heating inlet and outlet).

The water intake connectors do not need to be removed.

Changing the plate heat exchanger and the 3-way valve diaphragm:

To change these elements, part of the hydraulic unit must first be disassembled. The

whole unit is divided into two parts: unit 1 and unit 2 (see photograph 25).

Disassembling unit 1: (see photographs 23 and 24)

- Drain the heating circuit and the DHW circuit.
- Unplug the boiler from the mains.
- Disconnect the electrical connec-













tions, i.e. the 3-way valve micro switch and the thermistor connections.

- Remove the heating outlet pipe (2) from the hydraulic unit.
- Remove the pressure sensor from the heating return pipe, for ease of handling.
- Remove the heating outlet pipe (3) from the heat exchanger for ease of handling.

Remove the screws holding unit 1 to the boiler base (they are on the underside).

- Release unit 1 from the lower connectors (DHW inlet and outlet and heating outlet). The water intake connectors do not need to be removed.

Changing the plate heat exchanger :

- Remove the four screws holding the plate heat exchanger to unit 1 (be very careful with the O-rings; they should be changed).

Changing the 3-way valve diaphragm :

- Firstly, remove the plate heat exchanger.
- Remove the diaphragm cover (see photograph 26).



Changing the Pump :

- Drain the heating circuit and the domestic circuit.

- Remove the four Allen screws holding the pump body to the hydraulic unit, and remove the pump.

- Remove the pump electrical connection to the PCB.

Changing the drain valve :

- Drain the heating circuit.
- Remove the pump, and remove the clip holding the drain valve in place.

Changing the safety valve and drain valve :

Safety valve or drain valve: 2 and 3.

- 1. Drain the heating circuit.
- 2. Remove the clip and pull out the valve.

Changing the DHW thermistor :

Changing the DHW thermistor:

- Drain the DHW circuit.

- Remove the thermistor from its location and reuse the existing 'O' ring - DO NOT OVER TIGHTEN THE NEW THERMISTOR.









3.4.- Lighting up Sequence and Electrical Circuit

DHW start sequence FEB-24ED





Heating start sequence FEB-24ED





RE-start sequence FEB-24ED





DHW Service: FEB-24ED





Description of functioning

HEATING SERVICE FEB-24ED





Working mode change sequence: from Heating to DHW.





Electrical Circuit diagrams: FEB-24ED



- 1.- Mains connection (230v ac)
- 2.- Earth
- 3- Fan (230v ac)
- 4.- Pump (230v ac)
- 5.- Ignition (230v ac)
- 6.- Gas valve solenoid 1 (230v ac)
- 7.- Gas valve solenoid 2 (230v ac)
- 8.- Front panel control
- 9.- 3 way valve micro switch
- 10.- Air pressure switch
- 11.- Room stat (optional)
- 12.- Clock connection
- 13.- Modulating solenoid valve
- 14.- Ionisation electrode

- 15.- High limit stat
- 16.- DHW thermistor
- 17.- Central Heating thermistor
- 18.- CH low Pressure switch
- 19.- External Probe
- 20.- Clock (230 v ac)



MORCO PRODUCTS LTD Morco House Riverview Road Beverley East Yorkshire HU17 OLD Sales Telephone:01482 325456 Technical Helpline 01482 386586 Fax:01482 212869 email: sales@morcoproducts.co.uk web: www.morcoproducts.co.uk