HOT WATER OUTLET

AUTHORIT

INCOMPANY AND ADDRESS OF

COLD WATER INLET FROM THE WATER CONTROL ASSEMBLY

BRASS HOT WATER OUTLET EXTENSION UNION WATER CONTROL ASSEMBLY COLD WATER OUTLET PIPE TO HEAT EXCHANGER THIS IS A REPLACEMENT HEAT EXCHANGER, (FW0032), FOR THE G111E WATER HEATER.

PLEASE USE THE BRASS EXTENSION UNION FOR THE HOT WATER OUTLET AND THE COPPER PIPE FOR THE COLD WATER OUTLET FROM THE WATER CONTROL ASSEMBLY TO THE HEAT EXCHANGER.